

# **Phoenix Inverters**

250VA – 800VA 230V and 120V, 50Hz or 60Hz

www.victronenergy.com



Phoenix 12/375 VE.Direct



Phoenix 12/375 VE.Direct





### **VE.Direct communication port**

The VE.Direct port can be connected to:

- A computer (VE.Direct to USB interface cable needed)
- Apple and Android smartphones, tablets, MacBook's and other devices (VE.Direct Bluetooth Smart dongle needed)

### Fully configurable:

- Low battery voltage alarm trip and reset levels
- Low battery voltage cut-off and restart levels
- Dynamic cut-off: load dependent cut-off level
- Output voltage 210 245V
- Frequency 50 Hz or 60 Hz
- ECO mode on/off and ECO mode sense level

#### Monitoring:

In- and output voltage, % load and alarms

#### **Proven reliability**

The full bridge plus toroidal transformer topology has proven its reliability over many years. The inverters are short circuit proof and protected against overheating, whether due to overload or high ambient temperature.

### **High start-up power**

Needed to start loads such as power converters for LED lamps, halogen lamps or electric tools.

### **ECO** mode

When in ECO mode, the inverter will switch to standby when the load decreases below a preset value. Once in standby the inverter will switch on for a short period (adjustable, default: every 2,5 seconds). If the load exceeds a preset level, the inverter will remain on.

### Remote on/off

A remote on/off switch can be connected to a two pole connector, or between battery plus and the left hand contact of the two pole connector.


### **LED** diagnosis

Please see manual for a description.

### To transfer the load to another AC source: the automatic transfer switch

For our low power inverters we recommend our Filax Automatic Transfer Switch. The Filax features a very short switchover time (less than 20 milliseconds) so that computers and other electronic equipment will continue to operate without disruption.

## **Available with different output sockets**



### **Screw terminals**

No special tools needed for installation

|   | 12 Volt            | 12/250  | 12/375                             | 12/500                             | 12/800   |
|---|--------------------|---|------------------------------------|------------------------------------|--|
| Phoenix Inverter  | 24 Volt<br>48 Volt | 24/250<br>48/250  | 24/375<br>48/375                   | 24/500<br>48/500                   | 24/800<br>48/800   |
| Cont. power at 25°C (1)   |                    | 250VA   | 375VA                              | 500VA                              | 800VA  |
| Cont. power at 25°C / 40°C  |                    | 200 / 175W  | 300 / 260W                         | 400 / 350W                         | 650 / 560W   |
| Peak power  |                    | 400W  | 700W                               | 900W                               | 1500W  |
| Output AC voltage / frequency (adjustable)                                      |                    | 230VAC or 120VAC +/- 3% 50Hz or 60Hz +/- 0,1%   |                                    |                                    |  |
| Input voltage range   |                    | 9,2 - 17 / 18,4 - 34,0 / 36,8 - 62,0V   |                                    |                                    |  |
| DC low shut down (adjustable)   |                    | 9,3 / 18,6 / 37,2V  |                                    |                                    |  |
| Dynamic (load dependent) DC low (fully configurable)                            | v shut down        | Dynamic cut-off, see<br>https://www.victronenergy.com/live/ve.direct:phoenix-inverters-dynamic-cutoff         |                                    |                                    |  |
| DC low restart and alarm (adjustal  | ole)               | 10,9 / 21,8 / 43,6V   |                                    |                                    |  |
| Battery charged detect (adjustable)   |                    | 14,0 / 28,0 / 56,0V   |                                    |                                    |  |
| Max. efficiency   |                    | 87 / 88 / 88%   | 89 / 89 / 90%                      | 90/90/91%                          | 90 / 90 / 91%  |
| Zero-load power   |                    | 4,2 / 5,2 / 7,9W  | 5,6 / 6,1 / 8,5W                   | 6 / 6,5 / 9W                       | 6,5 / 7 / 9,5W   |
| Default zero-load power in ECO mode (default retry interval: 2,5 s, adjustable) |                    | 0,8 / 1,3 / 2,5W  | 0,9 / 1,4 / 2,6W                   | 1 / 1,5 / 3,0                      | 1 / 1,5 / 3,0  |
| ECO mode stop and start power se  | etting             | Adjustable  |                                    |                                    |  |
| Protection (2)  |                    | a-f   |                                    |                                    |  |
| Operating temperature range   |                    | -40 to +65°C (fan assisted cooling) Derate 1,25% per °C above 40°C  |                                    |                                    |  |
| Humidity (non-condensing)   |                    |   |                                    | 95%                                |  |
|   |                    | ENCLO   | SURE                               |                                    |  |
| Material & Colour   |                    | Steel chassis and plastic cover (blue Ral 5012)   |                                    |                                    |  |
| Battery-connection  |                    | Screw terminals   |                                    |                                    |  |
| Maximum cable cross-section   |                    | 10 mm <sup>2</sup> / AWG8   | 10 mm <sup>2</sup> / AWG8          | 10 mm <sup>2</sup> / AWG8          | 25 mm <sup>2</sup> / AWG4  |
| Standard AC outlets   |                    | 230V: Schuko (CEE 7/4), IEC-320 (male plug included)<br>UK (BS 1363), AU/NZ (AS/NZS 3112)<br>120V: Nema 5-15R |                                    |                                    |  |
| Protection category   |                    | IP 21   |                                    |                                    |  |
| Weight  |                    | 2,4kg / 5,3lbs  | 3,0kg / 6,6lbs                     | 3,9kg / 8.5lbs                     | 5,5kg / 12lbs  |
| Dimensions (hxwxd, mm)<br>(hxwxd, inch)   |                    | 86 x 165 x 260<br>3.4 x 6.5 x 10.2  | 86 x 165 x 260<br>3.4 x 6.5 x 10.2 | 86 x 172 x 275<br>3,4 x 6,8 x 10,8 | 105 x 216 x 305<br>4.1 x 8.5 x 12.1<br>(12V model:<br>105 x 230 x 325) |
|   |                    | ACCESS  | ORIES                              |                                    |  |
| Remote on-off   |                    | Yes   |                                    |                                    |  |
| Automatic transfer switch   |                    | Filax   |                                    |                                    |  |
|   |                    | STAND   | ARDS                               |                                    |  |
| Safety  |                    | EN-IEC 60335-1 / EN-IEC 62109-1   |                                    |                                    |  |
| EMC   |                    | EN 55014-1 / EN 55014-2 / IEC 61000-6-1 / IEC 61000-6-2 / IEC 61000-6-3                                       |                                    |                                    |  |
| Automotive Directive  |                    | ECE R10-4   |                                    |                                    |  |
| 1) Nonlinear load, crest factor 3:1 2) Protection key: a) output short circuit  |                    |   |                                    |                                    |  |



# **Battery Alarm**

An excessively high or low battery voltage is indicated by an audible and visual alarm, and a relay for remote signalling.



VE.Direct Bluetooth Smart dongle (must be ordered separately)



# **BMV Battery Monitor**

The BMV Battery Monitor features an advanced microprocessor control system combined with high resolution measuring systems for battery voltage and charge/discharge current. Besides this, the software includes complex calculation algorithms to exactly determine the state of charge of the battery. The BMV selectively displays battery voltage, current, consumed Ah or time to go. The monitor also stores a host of data regarding performance and use of the battery.

